



# Azpen A727 Back Cover Replacement

Removing Azpen A727 Back Cover.

Written By: lkmemphis



## INTRODUCTION

Use this guide to remove the back cover of the AZ 727. This may take a little time, so do not throw the device down in disgust.

---



### TOOLS:

- [Phillips #0 Screwdriver](#) (1)
  - [iFixit Opening Tools](#) (1)
-

## Step 1 — Back Cover



- Remove two 3mm screws with the Phillips screwdriver.

## Step 2



- Insert a plastic opening tool in the center then gently work towards the center.
- Work the opening tool around the edges to separate the back cover from the rest of the device.
- ❗ Once the first corner props open, the rest should open easily.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-15 12:39:54 PM.